



Fig. 5 Air flow diagram Utilus, Capitano und Mariner

- | | |
|---|--|
| 1 Intake filter | 13 TRIPLEX longlife cartridge |
| 2 Cylinder 1st stage | 14 Condensate drain valve |
| 3 Cylinder 2nd stage | 15 Pressure maintainig valve |
| 4 Cylinder 3rd stage | 16 Filling hose |
| 5 Inter-cooler 1st/2nd stage | 17 Filling valve |
| 6 Inter-cooler 2nd/3rd stage | 18 Final pressure gauge |
| 7 After-cooler | 19 Change-over device ^{a)} |
| 8 Safety valve 1st stage | 20 Safety valve, final pressure PN 200 ^{a)} |
| 9 Safety valve 2nd stage | |
| 10 Final pressure safety valve | |
| 11 Intermediate separator 2nd/3rd stage | |
| 12 Central filter assembly | |
- a) optional extra